Optional Automated Teach & Go Pressing

The Teach & Go option allows pressing positions to be stored on the first truss in a batch and other trusses will be automatically pressed without an operator.

A number of different truss types can be programmed into memory to allow different truss types to be pressed on the table at the same time.

- Subsequent trusses in batch pressed without operator required
- Multiple truss types can be stored in memory





The Truss Stacker moves the truss Horizontally on powered rollers and Automatically lifts it to a vertical position creating a stack of trusses with no operator required.

The Automated Truss Stacker combined with an Apex Table Press gives maximum production with the minimum number of operators required.

- No manual lifting required
- More production with less operatives





Telephone: +44 (0) 1746 714418 Email: enq@avbirch.co.uk



